

BERNICA

# Electric Heater Safety

Please read this booklet **before** using  
the **Hayes UK 2kW Fan Heater**

Keeping you safe in your home



Delivering  
exceptional  
housing  
services

On occasion we will provide you with temporary electric space heaters to help keep you warm while your main source of heating is being repaired.

Before using the electric heater it's important that you read this leaflet make sure you stay safe and keep warm.

## Things you should do

- Inspect the heater for cracked and broken plugs or loose connections before each use. If frayed, worn or damaged do not use.
- Place the heater on a stable and flat surface where there is minimum risk of it being knocked over.
- Keep the heater at least 1 meter away from things that can easily catch fire such as clothes, curtains, rugs, furniture and you.




## Things you shouldn't do

- **DO NOT** put anything flammable around the front, sides or rear of the heater.
- **DO NOT** use an extension cord or power strip unless you absolutely have to. These could cause the plug in wall socket to overheat and cause a fire.
- **DO NOT** place the heater on top of a table, chair or any other surface that is not stable.
- **DO NOT** operate the heater near water, anything that is damp or if you're wet.
- **DO NOT** run the power cord from the heater underneath carpets, rugs or furniture.
- **DO NOT** use the heater to dry clothes, warm bedding, cook food or thaw pipes
- **DO NOT** leave the heater on whilst sleeping.
- **DO NOT** leave children, the elderly or those with impaired mobility unattended around the heater.

## Remember!

If damaged, do not use the heater and report it as soon as possible.

**Do not attempt to repair the heater yourself**



# Operating the heater



Thermostat control dial



Operation control dial

- Plug the heater in and turn the thermostat control dial in a clockwise direction until it reaches the maximum setting.
- To heat at reduced power (1kw) turn the operation control dial to ●
- To heat at full power (2kw), turn the operation control dial to ●●
- When the room reaches a satisfactory temperature, turn the thermostat control anti-clockwise until the appliance switches off and not beyond; the heater will then regulate the temperature itself.
- For ventilation only, turn the operation control dial to ✪
- To switch off the heater turn the operation control dial to ○. Always unplug the heater when it is not being used.

## Remember!

You should have a smoke alarm in your home and you should be testing it weekly.

**Get it. Install it. Check it.**

**Smoke alarms save lives.**



- 1 Thermostat control dial
- 2 Indicator light
- 3 Operation control dial
- 4 Transport handle
- 5 Fire guard
- 6 Ventilation grills

## Need to contact us?



**Online:** [www.bernicia.com](http://www.bernicia.com)



**Email:** [contact@bernicia.com](mailto:contact@bernicia.com)



**Phone:** 0344 800 3800



**Letter:** Bernicia Group  
Oakwood Way  
Ashwood Business Park  
Ashington  
NE63 0XF

# BERNICIA

---

Bernicia Group is a Registered Society in England and Wales under the Co-operative and Community Benefit Societies Act 2014 No. 7711. Affiliated to the Federation of Housing Associations. Registered under the Housing and Regeneration Act 2008, Registration No. 4868. VAT Registration No.733 8036 38